



COLLAPSIBLE LOCKING INSTALLATION INSTRUCTIONS



1. Drill four (4) – ¾” holes into the ground surface through the baseplate for alignment.



2. Place anchors in holes and use a hammer to pound anchors into the ground.



3. Tighten anchors with wrench to lock base plate into place.



4. Use pad lock to lock bollard.



**Visit the Ideal Shield Youtube
Channel for video installation**

Ph: (866) 825-8659

Fax: (313) 842-7860

www.idealshield.com

Email: info@idealshield.com

2525 Clark St - Detroit, MI 48209



COLLAPSIBLE LOCKING INSTALLATION INSTRUCTIONS



1. Unlock bollard.



2. Lift bollard approximately 1".



3. Slowly lower bollard to resting position.



**Visit the Ideal Shield Youtube
Channel for video installation**

Ph: (866) 825-8659

Fax: (313) 842-7860

www.idealshield.com

Email: info@idealshield.com

2525 Clark St - Detroit, MI 48209